

# SQuape® R[s]

## Technical Data

- Rebuildable Tank Atomizer
- Diameter: 22 mm
- Height (without SQuip Tip) : 49mm
- Weight (without SQuip Tip): 65 g
- Connector thread: 510
- Airflowcontrol-Ring: SS - changeable (optional in brass, copper and different colors)
- Adjustable centerpin stainless steel
- Tank capacity: ~3.8 ml
- Material Tank: Stainless steel
- Material Base: Stainless steel
- Decks: Aluminium, ematal coated – non-conductive – convertible
- Chimney: Aluminium, ematal coated – non conductive
- Windows: Borosilicate glass, mattfinished
- SQuip Tip Nano, spare screws, o-rings and hexagon wrench (to remove the chimney) are included



## Description:

The SQuape R[s] – constructed on the basis of the SQuape V1 and R[eloaded] – underlies the same philosophy about making it a most ideal manageable atomizer. As a reliable everyday product it's for the ease of expert vapers as well as for rebuildable atomizer newbies. The device allows easy setups, it is short circuit safe; this is due to the averted electrical impulses. (The electric chamber is aluminium ematal coated\*). Short circuits are a thing of the past.

Compared to the SQuape R[eloaded] the new SQuape R[s] has only 49mm in height. The advantages of the SQuape R[eloaded] have been maintained and the SQuape R[s] is the complement to the „R“ version: Even the SQuape R[s] can be used with different decks! Five different decks allow optimal setups in terms of silica, cotton and mesh.

In addition, the SQuape R[s] was provided with an AFC (air-flow-control) which makes every vaper happy and no wishes are unfulfilled. The airholes in the AFC of 0.9, 1.1, 1.4, 1.8, 2.2 and 3.1mm allow drawing resistances that represents each vaper satisfied!

The SQuape R[s] will be sent in fully constructed usable condition, only the deck must be attached. Please pay attention to the enclosed instruction leaflet. In addition, spare screws, o-rings, a hexagon wrench and a the SQuip Tip Nano are in the standard set included.

## Decks:

You can build your setups on the SQuape R[s] with all kind of materials available on the market. The five different decks support personal preferences:

\*Ematal is an intensive process in the making of the topcoat for the aluminium item. In opposition to other specific oxidation methods this is supreme to a higher dimensional and a very tight surface structure. The anodic process adds a permanent and virtually scratch resistant surface to the functional parts made from aluminium. Highly stressed parts such as high pressure relief valves or materials from medical components which are made out of aluminium undergo this process. This is utilized due to the fact that there is less roughness by the movable parts thus less costly lubrication is required. Our advantage: ematal coated aluminium items are non-conductors!

Here we present possible wicks on the various decks:

**Deck S (standard):**



Silica 2mm 2x,  
0.20mm Kanthal



Cotton, Microcoil  
0.40 mm Kanthal



Mesh 300,  
0.20mm Kanthal

**Deck C (curved):**



Silica 4-fach,  
0.20mm Kanthal



Cotton, Microcoil, 0.40mm Kanthal

**Deck W (wide):**



Cotton, 3mm MC  
0.40mm Kanthal

**New:**

**Deck D (dual):**



Cotton, 2x3mm MC  
0.40mm Kanthal

**Deck B (bottom):**



Cotton, 3mm MC  
0.40mm Kanthal

Accurate instructions can be found on our YouTube channel: <https://www.youtube.com/user/StattQualm/playlists>

### **Important advices**

- The base cannot be disassembled (of course only the screws, the centerpin, decks and o-rings).
- For the dismantling of the chimney a hexagon wrench is included. The dismantling of the chimney eases the process of cleaning the vapor chamber.
- If you dismantle the glass tank please check the manual on [www.squape.ch](http://www.squape.ch) first. The glass behind the stainless steel tank is very stable and well protected. Assembly or disassembly may damage the glass.
- We recommend washing out the device before using it the first time.

### **How to clean the SQuape R[s]**

The SQuape R[s] allows cleaning in warm water. Due to the fact that the shell of the tank is not polished, there are no fingerprints visible. If you like to clean the tank inside, you simply need to remove the chimney with the provided hexagon wrench. Simply remove the tank with the wrench from the chimney by placing the wrench on the bottom of the bell and turning. Once the tank is cleaned, the chimney will be fastened in the same manner.

The StattQualm-Team wishes you much success and enjoyment with the SQuape R[s]!

A brand by  
**STATT**  
**QUALM**